



Abstracts

Session: 3

Paper Number: 44

**Automated Breathing and Metabolic Simulator (ABMS) CO<sub>2</sub> Test for Powered and Non-Powered Air-Purifying Respirators, Airline Respirators, and Gas Masks**

*N.L. Turner, E. Sinkule, S. Hota*

National Personal Protective Technology Laboratory, National Institute for Occupational Safety and Health

It has been estimated that several million workers are required to wear respirators. Elevated inhaled carbon dioxide concentration is an inherent aspect of respirator wear. The physiological effects of breathing 3 - 4% inhaled CO<sub>2</sub> are hyperventilation and headache. Previous data suggest that CO<sub>2</sub> concentrations in nonNIOSH-approved surgical helmets exceed the NIOSH REL of 0.5% and that CO<sub>2</sub> levels exceed the NIOSH STEL of 3% in a prototype powered air-purifying respirator operating with the blower turned off. There is currently no NIOSH certification test for CO<sub>2</sub> concentrations in air-purifying respirators.

For this study the Automated Breathing and Metabolic Simulator (ABMS), which simulates human metabolism, minute ventilation, and breathing waveforms, was used to characterize average inhaled CO<sub>2</sub> in a variety of NIOSH-approved air-purifying respirators. An ABMS CO<sub>2</sub> test protocol was developed to test 11 powered air-purifying respirators (PAPR's), 20 airline respirators (SAR's), six gas masks, 27 P-100 air-purifying respirators (APR's), and 26 filtering-facepiece N95 respirators (N95's). The ABMS CO<sub>2</sub> protocol consisted of the following levels of O<sub>2</sub> consumption, CO<sub>2</sub> production, and minute ventilation performed consecutively for a minimum of five minutes each: 0.5, 0.4, and 10 L/min STPD; 1.0, 0.8, and 25 L/min STPD; 1.5, 1.3, and 38 L/min STPD; 2.0, 1.9, and 62 L/min STPD; 2.5, 2.5, and 70 L/min STPD; and 3.0, 3.1, and 80 L/min STPD, respectively. The mean across all PAPR models for average inhaled CO<sub>2</sub> and O<sub>2</sub> ranged from 0.2% and 20.7%, respectively, for the lowest metabolic rate to 0.9% and 20.0%, respectively, for the greatest metabolic rate. The mean across all SAR's for average inhaled CO<sub>2</sub> and O<sub>2</sub> ranged from 0.5% and 20.3%, respectively, for the lowest metabolic rate to 0.4% and 20.5%, respectively, for the greatest metabolic rate. The mean across all gas masks and APR's for average inhaled CO<sub>2</sub> and O<sub>2</sub> ranged from 2.6% and 17.5%, respectively, for the lowest metabolic rate to 0.7% and 20.4%, respectively, for the greatest metabolic rate. The mean across all N95's for average inhaled CO<sub>2</sub> and O<sub>2</sub> ranged from 3.5% and 16.8%, respectively, for the lowest metabolic rate to 2.7% and 18.6%, respectively, for the greatest metabolic rate. These data demonstrate the wide range of average inhaled CO<sub>2</sub> concentrations across respirator types and the utility of the ABMS in conducting CO<sub>2</sub> testing.

20023576

# NORA Symposium 2003



## WORKING PARTNERSHIPS: APPLYING RESEARCH TO PRACTICE



June 23-24, 2003

Hilton Crystal City Hotel  
Arlington, VA

